105.00 mm


292.34 mm


APP USAGE INSTRUCTIONS

GuanYan


1-Scan the QR code on the instruction manual to download and install the APP

- 1-02 Download and Install the App






- 1-03 Installation Completed




2 - Register and log in to your account

- 2-01 Start and enter the app
- 2-02 After clicking Login, select Account Registration



- 2-03 Fill in the email account, password, and verification code




- 2-04 Registration Successful
- 2-05 Enter verification code to log in
- 2-06 Account logged in successfully




3 - Device Connection


- 3-01 Turn on the fusion splicer and select system settings




- 3-02 Bluetooth Settings - Turn On Bluetooth




- 3-03 On the mobile app login screen, click the Bluetooth icon




- 3-04 Select the corresponding Bluetooth name to connect



- 3-05 Bluetooth connection successful



When the Bluetooth connection is successful, the home page displays a blue status and shows information related to the fusion splicer




4 - Facility Management


- 4-01 Select the Facility Management icon on the left



- 4-02 Select a device



• 4-03 Enter the Facility Management page
Can modify the device name, view the device model, MAD code, and location, and delete the device




5-Facility Area


• Select a device on the home page and click




• Enter the Equipment Area




• 5-01 Welding Record




• Select a welding record and click to view the details of the welding record




• Select a welding record to send to email




• 5-02 Password Management
Add or reset password




• 5-03 Device Sharing



• Equipment Information
View device-related information



• 5-05 Mobile Bluetooth
After enabling, the device needs the phone to be powered on to start up



6-Personal Settings

• Click on the personal avatar on the home page to enter personal settings



• You can modify your profile picture, nickname, password, etc., or log out and cancel your account

